

Dreamy Creamy Cleanser

SH-02-33-03

Mild foaming cream cleanser that gently rinses away dirt, oil, and makeup leaving skin feeling soft and refreshed.



Dreamy Creamy Cleanser				
SH-02-33-03				
	Ingredients	INCI Nomenclature	Suppliers	% w / w
A	Natralipid® Meadowfoam	Limnanthes Alba (Meadowfoam) Seed Oil	Nature's Crops International	3.000
	Lipex® SheaClear™	Butyrospermum Parkii (Shea) Oil	AAK	3.000
	Instathix®	Xanthan Gum, Sodium Stearoyl Lactylate, Tapioca Starch, Algin	Alchemy Ingredients	2.500
B	DI-Water	Water (Aqua)	---	qs
	GreenGard™ PA	Phytic Acid	Green Line, LLC	0.100
	BergaSoft LG 50	Lauryl Glucoside	Berg + Schmidt	3.000
	Elfan® AT 84 G	Sodium Cocoyl Isethionate	Nouryon	4.000
	Propanediol	Propanediol	---	4.000
C	Original Extract™ Rice	Oryza Sativa (Rice) Bran Water	Gattefossé	5.000
	Natural Gardenia Red Powder Extract A-30 Type "N"	Hydrolyzed Gardenia Florida Extract, Maltodextrin	Omya	0.026
D	BergaCare SmartLipids	Water, Caprylic/Capric Triglyceride, Pentylene Glycol, Ceramide NP, Sodium Stearoyl Glutamate, Phytosterols, Ceramide AP, Stearic Acid, Oleic Acid, Palmitic Acid, Caprylyl Glycol, Propanediol, Glyceryl Caprylate	Berg + Schmidt	0.500
	Ceramide Light			
	Dewy Morning Fragrance ORC2002649	Fragrance	Orchidia Fragrances	0.750
	Evicide® rose 26	Phenethyl Alcohol, Ethylhexylglycerin	Evident Ingredients	1.000
				100.000

Procedure

1. Combine Phase B and begin mixing and heating to 70-75°C.
2. Premix Instathix® in Phase A in main mixing vessel. Add Phase B to Phase A and mix well until homogeneous.
3. Heat Phase AB to 70-75°C and maintain temperature for at least 10 minutes.
4. Homogenize for 3 minutes at 3500-5500 rpm.
5. Return to regular mixing. Pre-mix Phase C until fully dispersed and slowly add to Phase A/B at 40°C or below.
6. Add Phase C materials and mix well until homogeneous. Adjust pH to 5.5-6.0.

How To Use

Dispense product into hands. Massage gently onto damp skin and rinse with warm water.

Stability Tested	
3 months	5°C, room temperature, 40°C
3 weeks	50°C
Freeze/Thaw	3 cycles
Physical Data	
Appearance	Light Pink Emulsion
pH	5.5 – 6.0
Viscosity	3500 – 7500cPs Brookfield DV-II (RT; 24 hours; RV T-A (91) @10 rpm)



Omya Specialty Materials Inc.
5150 E. Pacific Coast Hwy, Suite 600
Long Beach, CA 90804
(877) 457-7266 | PersonalCareUS@omya.com

Innovation Comes Naturally™

Scan To Learn More

